





- 1 Brake light
- 2 Signal light
- 3 Switch interior light
- 4 Lupine SL AX headlight
- 5 Switch front headlight
- 6 Switch general on-off
- 7 Fuse
- 8 LED Blinkrelais Micro 1-30W, 12V
- 9 Horn 12V
- 10a, 10b Female connector 6.3 ST-005R
- 11 Constant current LED driver 30 Vdc 20 mA
- 12 Right/Left indicator front
- 13 Minature Buzzer 400 Hz
- 14 Horn button
- 15 Turn signal switch
- 16 Brake sensor
- 17 Rectifier Diotec 1N4007 1000 V 1 A
- 18 Battery
- 19 LED interior light
- 20 LED driver interior light